

COURSE TITLE: Pro Line 21[™] – King Air C90

Operator/Pilot Training

PREREQUISITES:

Students should have a basic knowledge of aircraft avionics systems and a working command of the English language. Students should be familiar with MS Windows® based Operating Systems.

PURPOSE:

This course provides training to familiarize pilots with the functionality of the Pro Line 21™ instrumentation.

OBJECTIVES: Upon completing this course, the student should be able to:

- 1. Identify Pro Line 21 Instrumentation.
- 2. Comprehend how Pro Line 21 components function in unison to provide the pilot flight information.
- 3. Perform the steps to:
 - a. Power up the Flight Management System (FMS)
 - b. Build a Flight Plan
 - c. Save and Load a Flight Plan
 - d. Enter Performance Data
 - e. Conduct Enroute Procedures
 - f. Execute a Missed Approach Procedure

COURSE LENGTH: 6 Hours



REFERENCES:

1.	FMS-3000 for the Beechcraft King Air C90GT/C90GTi/B200/B200C/	
	B200CGT/B300 Operator's Guide	523-0790066
2.	Pro Line 21 Avionics System with IFIS for the Beechcraft King Air	
	C90GT/C90GTi/B200GT/B200CGT Operator's Guide	523-0808535
3.	Pro Line 21 Avionics System with IFIS for the Beechcraft King Air	
	Operator's Guide	523-0807239
4.	FMS-3000 v4.0 Flight Management System for King Air Series Aircraft	
	Operator's Guide	523-0816977
5.	Pro Line 21 Avionics System with IFIS Upgrade for King Air Series	
	Operator's Guide	523-0817407



COURSE OUTLINE

- 0. Welcome & Introductions
 - A. Welcome to Rockwell Collins e-Learning
- 1. Primary Flight Display (PFD)
 - A. Introduction
 - B. Primary Flight Display (PFD)
 - i. Theory of Operation
 - ii. Description
 - iii. Operation
 - C. Display Control Panel (DCP)
 - i. Operation
 - D. Summary/Test

2. Multi-Function Display (MFD)

- A. Introduction
- B. Multi-Function Display (MFD)
 - i. Overview
 - ii. Description
 - iii. Operation
- C. Summary/Test

3. Flight Guidance Panel (FGP)

- A. Introduction
- B. Flight Guidance Panel (FGP)
 - i. Description
 - ii. Operation
- C. Flight Control Switches
 - i. Pitch Trim Command Switch



- ii. Autopilot/Yaw Damper (AP/YD) Disconnect (DISC) Button
- iii. Synchronize (SYNC) Button
- iv. GO AROUND Button
- D. Summary/Test

4. Integrated Flight Information System (IFIS)

- A. Introduction to IFIS-5000
 - i. Key Performance Features
- B. IFIS Line Replaceable Unit (LRU) Descriptions
 - i. File Server Unit (FSU)
 - ii. Adaptive Flight Display (AFD)
 - iii. Cursor Control Panel (CCP)
 - iv. XM Weather Receiver (XMWR) and Antenna
- C. IFIS Operations
 - i. Display Formats
 - ii. CCP Controls and Functions
- D. Summary/Test

5. Radio Sensor System (RSS)

- A. Introduction
- B. RSS Theory of Operation
- C. RSS Overview
 - i. Radio Tuning Unit (RTU) Functionality
 - ii. Control Display Unit (CDU) Functionality
 - iii. Reversionary Tuning
- D. RSS Operations
 - i. CDU
 - ii. RTU



- E. Summary/Test
- 6. Weather Radar System (WXR)
 - A. Introduction
 - B. WXR Description
 - i. Receiver/Transmitter Antenna (RTA)
 - C. How Radar Works
 - i. Performance
 - ii. Thunderstorms
 - iii. Reflection
 - iv. Calibrated Gain
 - D. WXR Modes of Operation and Features
 - i. Operational Mode
 - 1. DCP Controls
 - ii. Standby Mode
 - iii. Weather Only (WX) Mode
 - iv. Terrain Mapping (MAP) Mode
 - v. Test Mode
 - vi. Antenna Stabilization Feature
 - E. Summary/Test

7. CDU / Flight Management System (FMS)

- A. FMS System Overview
- B. CDU Familiarization
 - i. Operation
 - ii. Summary/Test
- C. FMS System Start-Up/Initialization Procedures (Guided Practice / Assessment)
 - i. Replace an Active Navigation Database with a Standby Database



- ii. Load a New Navigation Database
- iii. Synchronize a Newly Added Flight Plan
- iv. Initialize the FMS to Current Position
- v. Initialize the FMS to an Airport Code
- vi. Delete a Flight Plan
- D. Build a Flight Plan Procedures (Guided Practice / Assessment)
 - i. Enter an Origin Airport
 - ii. Enter a Destination Airport
 - iii. Enter an Alternate Airport
 - iv. Enter a Waypoint
 - v. Enter an Airway
 - vi. Delete a Flight Plan Discontinuity
 - vii. Repair a Flight Plan Discontinuity
 - viii. Delete a Flight Plan Waypoint
 - ix. Delete an Airway
 - x. Enter a Departure Runway
 - xi. Enter a Standard Instrument Departure (SID)
 - xii. Enter a Destination Approach and Transition
 - xiii. Adjust the Auto Sequence
 - xiv. Erase a Flight Plan
- E. Save and Load a Flight Plan Procedures (Guided Practice / Assessment)
 - i. Save a Flight Plan to a Pilot Route List
 - ii. Customize a Pilot Route Name
 - iii. Save the Flight Plan to a Disk
 - iv. Copy the Active Flight Plan to the Second Flight Plan
 - v. Activate a Second Flight Plan



- F. Performance Data Procedures (Guided Practice / Assessment)
 - i. Enter the Cruise Altitude
 - ii. Enter the Passenger Weight
 - iii. Enter the Cargo Weight
 - iv. Change the Sensed Fuel Value
- G. Enroute Procedures (Guided Practice / Assessment)
 - i. Delete a Flight Plan Discontinuity
 - ii. Enter a Hold
 - iii. Modify a Hold
 - iv. Insert a Direct-To Waypoint
 - v. Insert a Radial Intercept from a Heading Leg
 - vi. Insert a Radial and Distance Waypoint
 - vii. Insert an Off Airway Waypoint
- H. Missed Approach Procedures (Guided Practice / Assessment)
 - i. View the Missed Approach
 - ii. Sequence to the Missed Approach
 - iii. Sequence to the Alternate Flight Plan

8. Messages and Annunciations

- A. Introduction
- B. Engine Indicating System (EIS) Description
- C. Warning Flags and Alerts Description
- D. Display Reversion Description
- E. Summary/Test

9. Flight Plan Scenarios

- A. Original Flight Plan
- B. Flight Plan Re-Route



- C. Flight Plan Predicted Change
- D. Flight Plan Missed Approach

10.Summary

EQUIPMENT TYPE:

EQUIPMENT	NOMENCLATURE	PART NUMBER
Adaptive Flight Display	AFD-3010	822-1084-353 / 359 / 360
Adaptive Flight Display	AFD-3010E	822-1753-353 / 359 / 360
Display Control Panel	DCP-3030	822-1828-061 / 161
Flight Guidance Panel	FGP-3000	822-1107-103
File Server Unit	FSU-5010	822-1543-101
Cursor Control Panel	CCP-3000	822-1746-001
External Compensation Unit	ECU-3000	822-1200-998
XM Weather Receiver	XMWR-1000	822-2031-002
Control Display Unit	CDU-3000	822-0884-491 / 493
Radio Tuning Unit	RTU-4200	822-0668-251 / 261
Radio Tuning Unit	RTU-4220	822-0730-461
Receiver/Transmitter Antenna	RTA-800	822-1050-004
Receiver/Transmitter Antenna	RTA-852	622-8439-004